

Advantage™ PS Filter Cartridges

■ Polyethersulfone Membrane

Mega-Pure Membrane Series

High Flow Rate Capability With Polyethersulfone Membrane Filter Cartridges

Ultra-Pure polyethersulfone membrane cartridges provide superior flow rates over the competition. The unique construction features a high-surface area design that allows for excellent flow rates and high particle removal efficiency. Hydrophilic polyethersulfone membrane cartridges require no pretreatment and are ready to use. The Mega-Pure Polyethersulfone Membrane Series of filter cartridges meets or exceeds requirements for the filtration of UHP liquids used in the fabrication of state-of-the-art microelectronic devices.

The Mega-Pure Polyethersulfone Membrane Series is available in 0.03µm, 0.1µm and 0.2µm pore sizes.

Applications

UHP Water


- Central PAD
- Polishing Stations
- Point-of-Use

UHP Chemical

- Specialty Chemicals
- Point-of-Use
- Bulk Photoresists and Solvents

Microelectronics

- Semiconductor
- Optical Disks
- Printed Circuits
- Hard Disks



Features and Benefits

Superior Polyethersulfone Membrane Yields Maximum Filtration Results

- High surface area design provides excellent flow rates and extended filter life while maintaining high particle removal efficiency.
- Rinsed to 18 megohm-cm resistivity with UHP water.
- Spunbonded polypropylene support materials eliminate sites for potential shedding and increased particle counts.
- Provides broad chemical compatibility.

Parker's TQM System Assures Consistent Performance and Reliable Filtration

- Strict quality control measures include rigorous testing for rinse up, shedding, flow rate and extractable levels.
- Integrity-tested and testable *in situ*.
- Thermally welded, eliminating adhesive extractables.
- Biosafe in accordance with USP Class VI-121° Plastics Tests.
- Specifically designed to ensure cleanliness.
- All materials of construction are FDA listed as acceptable for potable and edible liquid contact according to CFR Title 21.

Process Filtration Division

WARNING! FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS AND/OR SYSTEMS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE. This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product and/or system options for further investigation by users having technical expertise. It is important that you analyze all aspects of your application and review the information concerning the product or system in the current product catalogue. Due to the variety of operating conditions and applications for these products or systems, the user, through its own analysis and testing, is solely responsible for making the final selection for the products and systems and assuring that all performance, safety and warning requirements of the application are met. The products described herein, including without limitation, product features, specifications, designs, availability and pricing, are subject to change by Parker Hannifin Corporation and its subsidiaries at any time without notice.

Parker
Filtration

Mega-Pure Membrane Series

Specifications

Materials of Construction:

- Membrane: hydrophilic polyethersulfone.
- Membrane Support Drainage: polypropylene.
- Structural Components: polypropylene.
- O-Ring Material: various.
- Sealing Method: thermal welding.

Dimensions:

- Diameter: 2.7 in (68mm).
- Lengths: 10-40 in (250-1020mm).

Surface Area:

- Minimum 6.5ft² (0.6 m²).

Integrity Test:

- Bubble Point (in UHP water).
 - 0.03µm ≥ 90 psig (6.2 bar).
 - 0.1µm ≥ 70 psig (4.8 bar).
 - 0.2µm ≥ 45 psig (3.1 bar).
- Diffusion Rate (10 in cartridge).
 - 0.03µm ≥ 30cc/min at 45 psig (3.1 bar).
 - 0.1µm ≥ 30cc/min at 40 psig (2.7 bar).
 - 0.2µm ≥ 30cc/min at 30 psig (2.1 bar).

Recommended Operating Conditions:

- Maximum Temperature: 176°F (80°C) @ 30 ΔP (2.1 bar).
- Maximum Differential Pressure:
 - Forward: 70 psi (4.8 bar) @ 77°F (25°C).
 - 30 psi (2.1 bar) @ 176°F (80°C).
 - Reverse: 50 psi (3.4 bar) @ 77°F (25°C).


Sterilization/Sanitization Methods:

- Isopropyl Alcohol.
- Sodium Hydroxide.
- Hydrogen Peroxide.
- 176°F (80°C) Water.

Polyethersulfone Cartridges:

Flow rate vs. ΔP for a 1 cps

liquid @ 73°F (23°C)**



Flow Factors:

Pore Size (µm)	l/min/ bar	bar/ l/min
0.03	66	0.015
0.1	99	0.010
0.2	192	0.005

Ordering Information

PS	F	B	10	E	TC	E
Cartridge Code	Pore Size (µm)	Diameter (mm)	Length (mm)	O-Ring Material	End Cap Configuration	Grade
PF = Polypropylene/ Polyethersulfone	T = 0.03 S = 0.1 F = 0.2	B = 68.6	10 = 254 20 = 508 30 = 762 40 = 1016	B = Buna N C = CR 503 D = CR 570 E = EPR L = KR 8201 S = Silicone T = PFA/Viton* V = Viton* X = No O-Ring	SC = 2-226 /Flat SF = 2-226 /Fin TC = 2-222/Flat TF = 2-222/Fin HH = DOE (Gaskets) AC = 020/Flat (Gelman) PC = 213/Flat (Ametek and Parker LT Polymeric Housings; Gelman H Style)	E = Electronics

Process Filtration Division

* Trademark of E.I. du Pont de Nemours & Co.
** Consult Process Filtration Division for gas flow data.

Parker Filtration
Filter Division Europe
Shaw Cross Business Park
Dewsbury, West Yorkshire
WF12 7RD, England
Phone: +44 (0) 1924 487000
Fax: +44 (0) 1924 487001
Website: www.parker.com

