

# High Flow Capacity Coreless Pleated Filter Cartridges

Parker's Fulflo® MegaFlow<sup>™</sup> cartridges provide a cost effective alternative to wound and other 63mm OD style filter cartridges in high flow applications such as reverse osmosis pre-filtration and similar applications where nominal efficiency is sufficient. Each MegaFlow<sup>™</sup> cartridge can handle flow rates up to 950 lpm, significantly reducing the number of cartridges required and the housing size. Each 6 inch (152 mm) diameter MegaFlow<sup>™</sup> cartridge has flow capicity equal to 10 standard 63mm OD X 1016mm long filter cartridges. Positive O-ring seals and a built in handle make cartridge installation reliable, fast and easy.

MegaFlow<sup>™</sup> cartridges are available in either pleated polypropylene or cellulose media with nominal

# Applications

- Potable Water
- Reverse Osmosis Pre-Filtration
- Petrochemicals
- Waste Water
- Lubricating Oil
- Coolants

# Features and Benefits

- High flow capacity means fewer cartridges and reduces labor costs to change.
- High flow capacity allows smaller housings and less capital expenditure.
- Coreless construction reduces disposal volume and cost.
- Built in handle makes change fast, easy and safe.
- O-ring seal assures filtration integrity.
- Choice of polypropylene or cellulose media allows use in both aqueous and non-aqueous fluid applications.

# Fulflo<sup>®</sup> MegaFlow<sup>™</sup> Filter Cartridges

- Polypropylene
- Cellulose

# **Pleated Series**



- Thermally bonded polypropylene and phenolic resin bonded cellulose filter media prevent particle bleed through and unloading that commonly occurs with wound cartridges.
- High surface area pleated design provides lower pressure drop and longer service life than other cartridges.
- All materials of construction in polypropylene cartridges comply with FDA regulations per CFR Title 21.
- Horizontal and vertical housings are available for flow rates up to 4,750 gpm (18,000 LPM)

# **Process Filtration Division**

WARNING! FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS AND/OR SYSTEMS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE. This document and other information from Parker Hannlin Corporation, its subsidiaries distributors provide product and/or system options for further investigation by users having technical expertise. It is important that you analyse all aspects of your application and review the information concerning the product or system in the urrent product catalogue. Due to the variety of operating conditions and applications for these products or systems, the user, through its own analysis and testing, is solely responsible for making the final selection for the products and assumg that all performance, safety and warning requirements of the application and review availability and pricing, are subject to change by Parker Hannlin Corporation and its subsidiaries at any time without noice.



### **Specifications**

**Nominal Filtration Ratings (90%)** 

0.5, 1, 5 and 10 μm

### **Materials of Construction:**

Media:	Polypropylene microfiber				
	(P Code)				
	Cellulose with				
	phenolic binder (C Code)				
Support Layers:	Polypropylene (P Code)				
	None (C Code)				
End caps:	Glass Filled Polypropylene				
O-Rings:	Buna N, EPR, Silicone,				
	Fluoroelastomer				

### **Dimensions:**

6 in (152 mm) OD, 3.5 in (89 mm) ID, 40 in (1016 mm) long

**Surface Area:** 55 - 60 ft<sup>2</sup> (5.1 - 5.6 m<sup>2</sup>)

### **Recommended Operating Conditions:**

Change Out Differential Pressure: Maximum Flow Rate: Maximum Temperature: Maximum Differential Pressure:

35 psid (2.4 bar) 250 gpm (950 lpm) 200°F (93°C) 150 psid (10 bar)

Cartridge	Nominal	Media	Rem	oval Ratir	Flow Factor*			
Code	Rating		90%	95%	98%	99%	99.9%	(Mbar/lpm)]
MFNP005	0.5	Polypropylene	0.5	1	2	5	10	0.06
MFNP010	1	Polypropylene	1	3	7	10	30	0.014
MFNP050	5	Polypropylene	5	10	20	30	50	0.008
MFNP100	10	Polypropylene	10	30	50	60	90	0.006
MFNC005	0.5	Cellulose	0.5	1	2	3	10	0.03
MFNC010	1	Cellulose	1	2	3	5	20	0.003
MFNC050	5	Cellulose	5	8	10	15	85	0.002
MFNC100	10	Cellulose	10	12	15	30	100	0.0009

\*In water at 1 cks

#### Flow Rate and Pressure Drop Formulas:

Flow Rate l/min = Clean ∆P Viscosity x Flow Factor

Clean △P = Flow Rate x Viscosity x Flow Factor

#### Notes:

1. Clean  $\Delta P$  is mbar differential at start.

- 2. Viscosity is centistokes.
- Use Conversion Tables for other units.
- 3. Flow Factor is mbar-l/min at 1 cks

# **Ordering Information**

MFN	C	050	40 —	N
Cartridge Code	 Media	 Micron Rating	Length	O-Ring Material
MegaFlow™ Nominal Series	P = Polypropylene C = Cellulose	005 - 0.5 μm 010 - 1 μm 050 - 5 μm 100 - 10 μm	40 = 40" 1016mm	N = Buna N E = EPR S = Silicone V = Fluoroelastomer

# **Process Filtration Division**

